

TELEPHONE FEATURES

ABBREVIATED DIALING WITH ITE-4 AND STE

To add or change a number:

- 1** Lift the handset.
- 2** You should hear the dial tone.
- 3** Press **#** **4** ***** .
- 4** You should hear a beep.
- 5** Enter the new number.
- 6** You should hear two beeps.
- 7** Hang up.

To place a call:

- 1** Lift the handset.
- 2** You should hear the dial tone.
- 3** Press **#** **4** .
- 4** The call should go through to the number dialed.