

## TELEPHONE FEATURES

---

### *DO NOT DISTURB, USING ITE-4 AND STE*

To block incoming calls:

- 1** Lift the handset.
- 2** You should hear the dial tone.
- 3** Press **\*** **6** .
- 4** You should hear two beeps.
- 5** Hang up.

To unblock incoming calls:

- 1** Lift the handset.
- 2** You should hear, "Private. Private."
- 3** Press **#** **6** .
- 4** You should hear two beeps.
- 5** Hang up.