

TELEPHONE FEATURES

HOLD/ALTERNATE TWO CALLS, USING ITE-4

To place a call on hold:

- 1** Press **HOLD** .
- 2** The call should now be on hold.

To retrieve a call from hold:

- 1** Lift the handset.
- 2** You should hear, "Held. Held."
- 3** You should hear the dial tone.
- 4** Press **HOLD** .
- 5** You should be reconnected to the call.

To alternate between two calls:

- 1** Press **HOLD** .
- 2** You should hear the dial tone.
- 3** Dial the second phone number.
- 4** Press **HOLD** .
- 5** You should be reconnected to the first call.