

## TELEPHONE FEATURES

---

### **DIAL INTERCOM ON ITE-12+, 12S, 24, AND 30S**

To place an intercom call:

- 1** Press **INTCM** .
- 2** Lift the handset.
- 3** The **INTCM** lamp should be ON.
- 4** You should hear the dial tone.
- 5** Dial the intercom number.

To answer an intercom call:

- 1** The **INTCM** lamp should blink when the phone rings.
- 2** Press **INTCM** .
- 3** Lift the handset.
- 4** The **INTCM** lamp should stay ON without blinking.