## **TELEPHONE FEATURES**

HOLD/ALTERNATE USING ITE-12+, 12S, 24, AND 30S

1 Press HOLD	
2 The EXT lamp should be blinking.	

